

Table of Contents

Getting started

- 8 Device layout
- 9 Key names and functions
- 10 Package contents
- 11 USIM Card
- 14 Charging the battery
- 16 Inserting a SD Card
- 18 Turning the device on and off
- 19 Initializing this device
- 20 Locking and unlocking the device
- 20 Adjusting the volume
- 20 Switching to silent mode

Basics

- 21 Status bar icons
- 22 Using the Display
- 25 Palm motions
- 26 Using Multi Window
- 30 Notifications window
- 31 Home screen
- 33 Applications list
- 34 Using applications
- 35 Entering text
- 37 Connecting to a Wi-Fi network
- 38 Setting up accounts
- 39 Transferring files
- 40 Security Codes

- 40 USIM PIN
- 41 Securing the device
- 42 Updating software

Communication

- 44 Contacts
- 48 SoftBank Mail
- 50 Email
- 52 Gmail
- 53 Google+
- 54 Photos

Web & network

- 55 Internet
- 57 Chrome
- 58 Bluetooth
- 59 Screen Mirroring

Media

- 60 Music
- 62 Camera
- 67 Gallery
- 70 Video
- 71 YouTube

Application & media stores

- 72 Play Store
- 73 GALAXY Apps
- 73 Play Books
- 74 Play Movies & TV
- 74 Play Games

Utilities

- 75 Memo
- 77 S Planner
- 79 Dropbox
- 80 Cloud
- 80 Drive
- 81 Hancm Office Viewer
- 84 Alarm
- 85 World Clock
- 85 Calculator
- 86 S Voice
- 87 Google
- 87 Voice Search
- 88 My Files

Travel & local

- 91 Maps

Settings

- 92 About Settings
- 92 Connections
- 97 Device
- 101 Controls
- 105 General
- 108 Google Settings

Troubleshooting

Specifications

- 114 Device
- 115 Materials

Warranty & After-Sales Service

- 116 Warranty
- 116 After-Sales Service

Customer Service

About this manual

This user manual details information about the device's functions and features.

You can check this manual on the device or using a computer.

- You can download the latest version of this manual from the SoftBank Mobile Website.
<http://www.softbank.jp/mobile/support/product/galaxy-tab4/>
- Please read this manual before using the device to ensure safe and proper use.
- Descriptions are based on the device's default settings.
- Unauthorized reproduction of all or part of this manual is prohibited.
- The content of this manual is subject to change without prior notice.
- All care has been taken with the content of this manual; however, please contact us if you find any errors or missing data.
- Content (high quality content) that requires high CPU and RAM usage will affect the overall performance of the device. Applications related to the content may not work properly depending on the device's specifications and the environment that it is used in.
- Applications and their functions may vary by country, region, or hardware specifications. SoftBank Mobile Corp. is not liable for performance issues caused by applications from any provider other than SoftBank Mobile Corp.
- Software, sound sources, wallpapers, images, and other media provided with this device are licensed for limited use. Extracting and using these materials for commercial or other purposes is an infringement of copyright laws. Users are entirely responsible for illegal use of media.
- You may incur additional charges for data services, such as messaging, uploading and downloading, auto-syncing, or using location services. To avoid additional charges, select an appropriate data tariff plan. For more details, contact Customer Service or contact a SoftBank Shop.
- Default applications that come with the device are subject to updates and may no longer be supported without prior notice. If you have any questions regarding the applications pre-installed on your device, please contact Customer Service or contact a SoftBank Shop. For user-installed applications, contact service providers.

- You can install various applications on this device using Google Play™ operated by Google Inc. SoftBank Mobile Corp. does not guarantee the content (quality, authenticity, legality, fitness for purpose, credibility of information, and accuracy) of any applications that you install and any faults (viruses, etc.) caused by those applications.

Instructional icons



Warning: situations that could cause injury to yourself or others



Caution: situations that could cause damage to your device or other equipment



Note: notes, usage tips, or additional information

Copyright

Copyrights

Sounds, images, computer programs, databases, other copyrighted materials, their respective works and copyright holders are protected by copyright law. Duplicated materials are limited to private use only. If duplications (including conversion of data types), modifications, transfer of duplicates or distribution on networks are made without permission of copyright holders, it constitutes "Literary Piracy" and "Infringement of Copyright Holder Rights" and a lawsuit for reparations may be filed and may result in criminal punishment. If duplicates are made using device, please observe the copyright laws. Materials captured with device Camera are also subject to the above.

Portrait Rights

Individuals have the right to refuse being photographed or publication or use of their image. Personality rights, or Right of Publicity, is a form of property right designed to protect celebrity interests that applies to all people. Be careful when using device Camera. Photographing or distributing the images of others without permission is unlawful.

Trademarks

- SAMSUNG and the SAMSUNG logo are registered trademarks of Samsung Electronics.
- Bluetooth® is a registered trademark of Bluetooth SIG, Inc. worldwide.
- Wi-Fi®, Wi-Fi Protected Setup™, Wi-Fi Direct™, Wi-Fi CERTIFIED™, and the Wi-Fi logo are registered trademarks of the Wi-Fi Alliance.
This device uses anharmonic frequency that is compatible with all European countries. In the EU, usage of wireless LAN indoors is not regulated but it cannot be used outdoors.
- Yahoo! and the Yahoo! logo "Y!" are trademarks or registered trademarks of Yahoo! Inc. in the US.
- The Viewn name and logo are trademarks of Viewn Corporation.
- UULA® is a registered trademark of the UULA Corporation.
- Internet SagiWall is a trademark or registered trademark of the BB Softservice Corporation.
- McAfee and other marks are registered trademarks and/or trademarks of McAfee, Inc. and/or affiliated companies in the US and/or other countries. The red associated with security is a color that is specific to the McAfee brand product.
- S! Mail and Raku Deco are trademarks and/or registered trademarks of the SoftBank Mobile Corporation.
- ©SoftBank Mobile Corp. /Powered by MediaDo

- Technology is provided by ACCESS CO., LTD. for this product.

©2011 ACCESS CO., LTD. All rights reserved.

Copyright © 2009 The Android Open Source Project Licensed under the Apache License, Version 2.0 (the "License");

you may not use this file except in compliance with the License.

You may obtain a copy of the License at

<http://www.apache.org/licenses/LICENSE-2.0>

Unless required by applicable law or agreed to in writing, software distributed under the License is distributed on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied.

See the License for the specific language governing permissions and limitations under the License.

ACCESS and the ACCESS logo are trademarks and/or registered trademarks of ACCESS CO., LTD. in Japan, the US, and/or other countries.



- All other trademarks and copyrights are the property of their respective owners.