

Before Using Browser	P.5-2	Browser Settings	P.5-8
About SSL/TLS	P.5-2	Setting Privacy/Security	P.5-8
Using Browser	P.5-2	Setting Font Size	P.5-10
Browser Window	P.5-2	Selecting Search Engine	P.5-10
Using Browser Menu	P.5-3	Resetting Browser Settings	P.5-10
Operations While Using Browser			
.....	P.5-3		
Scrolling the Screen	P.5-3		
Stopping Loading Webpages	P.5-3		
Going Back to Previous Screen	P.5-3		
Using Menu of Browser Window	P.5-4		
My SoftBank	P.5-4		
Bookmark	P.5-5		
Registering Bookmark	P.5-5		
Viewing Bookmark	P.5-5		
Browsing History	P.5-5		
Using Downloaded Data	P.5-6		
Checking Downloaded Data	P.5-6		
Changing View Mode of Downloaded Data			
List Window	P.5-6		
Deleting Data	P.5-6		
Sending Data by S!Mail	P.5-7		
Editing Titles	P.5-7		
Viewing Details	P.5-7		

Before Using Browser

About SSL/TLS

Secure Sockets Layer (SSL) and Transport Layer Security (TLS) are encryption protocols that secure Internet transmissions of important/sensitive information such as credit card numbers and corporate secrets, providing protection against online threats (eavesdropping, falsification, impersonation, etc.).

CAUTION

- When opening a secured page, users must decide as their responsibility whether or not to open the page with use of SSL/TLS. SoftBank Corp. and the Certification Authorities Symantec Website Security G.K. and Cybertrust make no guarantees whatsoever to users regarding security of SSL/TLS.

Using Browser

View various websites or homepages by connecting to Internet.

Internet search by keyword is also available.

7 in Standby

Browser window appears.

- If Confirmation window appears, select "Yes." In Confirmation window, check "Don't ask again" () → "Yes" not to show Confirmation window from next time.

Browser Window

In Standby, press  to show Browser window.



Browser Window

- Site name
- Contents
- The number of tabs

The number of opened tabs appears.

Using Browser Menu

View Bookmark list, check Browsing history, make settings for browser, etc.


1 Long Press  in Standby

2 Select each item


Item	Description
Homepage	Show Homepage. (P.5-2)
My SoftBank	Connect to My SoftBank. (P.5-4)
Bookmark	Show Bookmark list. (P.5-5)
Web Search	Enter keyword or URL to show website.
History	Show History window. (P.5-5)
Download	Show downloaded data list window. (P.5-6)
Browser Settings	Show Browser Settings window. (P.5-8)

Scrolling the Screen

1  in Browser window


- Long Press  to scroll the screen continuously.

Stopping Loading Webpages

1  (Stop) in Browser window

- Only available during webpage-loading.

Going Back to Previous Screen

1  (Back) in Browser window

- To go to next screen,  (Menu) → "Forward."

Using Menu of Browser Window

Operations for Bookmark, Browsing history view, etc. are available.


1 In Browser window,  (Menu) → Select each item

Item	Description
Bookmark	Show Bookmark list. (P.5-5)
Regist Bookmark	Register the current website to Bookmark. (P.5-5)
History	Show History window. (P.5-5)
Web Search	Enter keyword or URL to show website.
Tab	Show the displayed tab list.
Reload	Reload to update website.
Forward	Go to next screen.
Pointer	Show Pointer.
Browser Settings	Make Browser Settings. (P.5-8)

Connect to My SoftBank.



1 Long Press  in Standby → "My SoftBank"

My SoftBank appears.




- Alternatively, in Standby,  → "Settings" → "Number/Address Settings" → "Visit My Softbank" to show My SoftBank.

Bookmark







■ Registering Bookmark

- 1 In Standby,  → Show website to register
- 2  (Menu) → "Regist Bookmark" → "Yes"
Bookmark is registered.

■ Viewing Bookmark


- 1 In Standby, Long Press  → "Bookmark"
Bookmark list window appears.
 - Alternatively, in Browser window,  (Menu) → "Bookmark" to show Bookmark.
- 2 Select Bookmark →  (Open)
Website registered to Bookmark appears.


Browsing History

- 1 In Standby, Long Press  → "History"
History window appears.
 - Alternatively, in Browser window,  (Menu) → "History" to show History.
 -  (Menu) → "Open in new tab" to show in new tab.
 - Select History to delete →  (Menu) → "Delete" → "Yes" to delete History.
 - Select History →  (Detail) to show Web page information.
- 2 Select History →  (Open)
Website appears.

Using Downloaded Data


■ Checking Downloaded Data

1 In Standby, Long Press  → "Download"
Downloaded data list window appears.


2 Select data → 
The data is played/shown.

■ Changing View Mode of Downloaded Data List Window

Set View Mode of downloaded data list window.



1 In Downloaded data list window, 
(Menu) → "View Mode" → "Thumbnail"/"List"/"List(Details)"
View Mode is changed.

■ Deleting Data


1 In Downloaded data list window, 
(Menu) → "Delete"

2 "Delete One" → "Yes"
The data is deleted.

■ To delete multiple data

"Delete Multiple" → Check data () to delete →  (Delete) → "Yes"
• While selecting downloaded data to delete, 
(Menu) → "Check all"/"Uncheck all" to select/cancel all the data.

■ Sending Data by S!Mail

1 In Downloaded data list window, 
(Menu) → "Send"


2 "Send One"

New S!Mail composition window with data attached to appears.





- For the following operations, see "Creating/Sending S!Mail" (P.4-6).

■ To attach multiple contacts

"Send Multiple" → Check data () to send → 
(Send)


- While selecting data to send,  (Menu) → "Check all"/"Uncheck all" to select/cancel all the data.
- For the following operations, see "Creating/Sending S!Mail" (P.4-6).

■ Editing Titles

1 In Downloaded data list window, select data →  (Menu) → "Edit Title" → 
→ Edit the title →  →  (Done)

The data title is changed.

■ Viewing Details


1 In Downloaded data list window, select data →  (Menu) → "Details" → "OK"
Details on data appear.

Browser Settings

Set Browser operations.

1 In Standby,  →  (Menu) → "Browser Settings"

Browser Settings window appears.

- Alternatively, in Standby, Long Press  → "Browser Settings" to show the window.

2 Set each item

Item	Description
Privacy/Security	Make settings for Browser security such as Cache, deleting browsing history. (P.5-8)
Font Size	Set displayed Font Size. (P.5-10)
Search Engine	Select Search Engine. (P.5-10)
Browser Reset	Reset Browser Settings. (P.5-10)

Setting Privacy/Security

Delete Cache, browsing history and set Cookies.

Deleting Cache

1 "Privacy/Security" in Browser Settings window

2 "Clear Cache" → "Yes"
Cache is deleted.

Deleting History

Delete all saved browsing history.

1 "Privacy/Security" in Browser Settings window

2 "Clear History" → "Yes"
Browsing history is deleted.

■ Accepting Cookie

Set whether to save and accept Cookies.

1 "Privacy/Security" in Browser Settings window

2 Check/Uncheck "Accept Cookies" () / ()

Saving and accepting Cookies are enabled/disabled.

■ Deleting Cookies

1 "Privacy/Security" in Browser Settings window

2 "Clear all Cookies" → "Yes"
Cookies are deleted.

■ Enabling Javascript

Set whether to use Javascript.

1 "Privacy/Security" in Browser Settings window

2 Check/Uncheck "Enable Javascript" () / ()

Javascript is enabled/disabled.

■ Blocking Pop-ups

Set whether to show Pop-ups in Browser window.

1 "Privacy/Security" in Browser Settings window

2 Check/Uncheck "Block Pop-ups" () / ()

Pop-ups are blocked/unblocked.

■ Setting Font Size

Set displayed Font Size in Browser.

- 1 In Browser Settings window, "Font Size" → "Large"/"Middle"/"Small"
Font Size is changed.

■ Selecting Search Engine

Select Search Engine for keyword search.

- 1 In Browser Settings window, "Search Engine" → "Google"/"Yahoo! JAPAN"/"Bing"
Search Engine is set.

■ Resetting Browser Settings

- 1 In Browser Settings window, "Browser Reset" → "Yes"
Browser Settings are reset to default.